

1 / 4

FIG. 1




FIG. 2





FIG. 3



This exploded perspective view shows the assembly of the electronic device 100. The top cover 26 is positioned above the base 25. The base 25 features a central area 22 where components are mounted. A display unit 11 is shown in its retracted position, connected to the base by a hinge mechanism 12. The hinge mechanism includes a pivot 13 and a spring 14. A button 15 is also shown. The base 25 has a recessed area 26a for the display unit 11. The top cover 26 has a corresponding recessed area 26a for the base 25. The device 100 is shown in a disassembled state, with the top cover 26, base 25, display unit 11, and various components (1, 2, 3, 4, 12, 13, 14, 15) shown in their relative positions.

4 / 4

FIG. 5
PRIOR ART




FIG. 6
PRIOR ART

